



Instruction guide

**HONDA RUBICON
(TRX 500)
2005 ET 2006**

Assembly:

1. Take off the original muffler



2. Clean all around the pipe with a sand paper



3. Install the replacement muffler Exsound



Very important:

Put back the heat shield of the original inlet pipe with the replacement inlet pipe of the Exsound muffler

Note:

The collars are going to the same place